



## MEASURING FOR STAIR WAINSCOT

### MEASUREMENTS

A: RISER HEIGHT- MEASURE FROM TOP OF TREAD TO TOP OF TREAD

B: TREAD DEPTH (EXCLUDING NOSING)- MEASURE FROM FACE OF RISER TO FACE OF RISER. NOTE: DO NOT INCLUDE NOSING THAT EXTENDES PAST RISER IN YOUR MEASUREMENT.

C: SKIRT BOARD LENGTH- MEASURE THE TOTAL LENGTH OF THE ANGLED SKIRT BOARD.

D: SKIRT BOARD RISE AT BOTTOM OF STAIRS- MEASURE THE RISE OF THE SKIRT BOARD AT THE BOTTOM OF THE STAIRS MEASURING FROM THE FLOOR LINE TO THE START OF THE ANGLE. NOTE: IN SOME CASES THIS DIMENSION MAY BE ZERO.

E: SKIRT BOARD RISE AT TOP OF STAIRS- MEASURE THE RISE OF THE SKIRT BOARD AT THE TOP OF THE STAIRS MEASURING FROM THE FLOOR LINE TO THE START OF THE ANGLE. NOTE: IN SOME CASES THIS DIMENSION MAY BE ZERO.

## MEASURING FOR NON-STANDARD WAINSCOT BELOW THE STAIRS

### MEASUREMENTS

A: RISER HEIGHT- MEASURE FROM TOP OF TREAD TO TOP OF TREAD

B: TREAD DEPTH (EXCLUDING NOSING)- MEASURE FROM FACE OF RISER TO FACE OF RISER. NOTE: DO NOT INCLUDE NOSING THAT EXTENDES PAST RISER IN YOUR MEASUREMENT.

F: MEASURE THE TOTAL DISTANCE, BELOW THE STAIR SKIRT BOARD, WHERE THE WAINSCOT WILL BE INSTALLED.

NOTE: MEASUREMENTS "A" & "B" ARE REQUIRED TO CALCULATE THE ANGLE OF THE NON-STANDARD WAINSCOT.